


leziter®

Como kerti hintaágy


szereelési útmutató



			
A1 – x2	A2 – x2	B – x1	C – x1
			
D – x2	E – x1	F – x1	G – x4
			
I – x2	J – x1	K – x2	L – x2
			
M – x1		P – x2	Q – x6 (M6x45)
			
R – x4 (M6x55)	R1 – x2 (M6x35)	S – x4 (M6x63)	T – x3 (M6x25)
	 M6	 M6	
U – x4 (M6x88)	V – x23	W – x23	Y – x2
	 M6		
Y1 – x2	Z – x23	Z1 – x1	Z2 – x2




B	x1
C	x1
Q	x2
W	x2
V	x2
Z	x2




A1	x2
A2	x2
U	x4
W	x4
V	x4
Z	x4

3




D	x2
Q	x4
W	x4
V	x4
Z	x4

4




E	x1
F	x1
W	x1
V	x1
Z	x1
T	x1

5




S	x4
W	x4
V	x4
Z	x4

6




I	x2
J	x1
R	x2
W	x2
V	x2
Z	x2

7




G	x4
R	x2
R1	x2
W	x4
V	x4
Z	x4

8




P	x2
---	----

9




K	x2
Y	x2
Y1	x2
T	x2

10



M	x1
L	x2

11



12

