

14.25X21cm

Összerelési útmutató



9

K × 2
Y × 2
Y1 × 2
T × 2

10

M × 1
L × 2

11

12

N × 1

A1 2	A2 2	B1 1	C1 1
D1 2	E1 1	F1 1	G1 4
H1 2	I1 1	J1 2	K1 2
L1 1	M1 1	N1 2	O1 6
P1 4	Q1 2	R1 4	S1 3

U1 4	V1 23	W1 23	Y1 2
Z1 2	Z2 23	Z1 1	Z2 1

1

B × 1
C × 1
D × 2
V × 2
Z × 2

2

A1 × 2
A2 × 2
U × 4
V × 4
W × 4
Z × 4

3

D × 2
Q × 4
N × 4
W × 4
X × 4
Z × 4

4

B × 1
P × 1
W × 1
X × 1
Y × 1

5

S × 4
N × 4
X × 4
Z × 4

6

I × 2
J × 1
R × 2
W × 2
V × 2
Z × 2

7

G × 4
R × 2
R1 × 2
W × 4
V × 4
Z × 4

8

P × 2